

MEDRAD ATD-Torso Configuration File Information

9X software

The **ATDTORSO** configuration file is located in the Available Coil List in the Configuration File Manager. The coil name needs to be added to the Site List. Save Changes and system a re-boot is necessary.

Please see the Technical Tip Bulletin Board to ensure the Torso array in use is compatible with the **ATDTORSO**.

Please Call **1800 MRCOILS** with any questions.